


## Injection nipples and valve 6,1mm



Filoform injection nipples and injection valves are used for injection joints. The injection valve is positioned on the wrap-around gauze by using the wrap-around tape. The injection nipple is placed onto the resin pack in order to enable an easy and smooth injection of the resin into the joint. Recommended for injection joints on cables



# Injection nipples and valve 6,1mm

## Spezifikationen

Material	polystyrene
Inner diameter opening	6,1mm
Outer diameter	Suitable for all common types of injectionvalves of 6,1mm
Version	Adhesive foam ring with a removable protection foilVery good adhesion, even with high and low temperatures.Suitable for all common types of resin packages.
Nipple construction	The resin package opens with the pressure of the injection pump.The nipple has 8 perforation teeth.

Injectionnipple 6,1mm

Material	Polyethylene
Inner diameter opening	9,9mm
Diameter plate	55mm
Version	Suitable for all common type of injectionnipples 6,1mm.
Valve construction	Provided with a non-return valve to prevent leakage of the resin

Injectionvalve 6,1mm

# Injection nipples and valve 6,1mm

## Produkte

Art.nr.	Artikelname	Bestelleinheit
80381	Injection nipple 6,1mm	10 pcs/bag
80535	Injection valve 6,1mm	10 pcs/bag