


## Injection nipples and valve 12,2mm



Filoform injection nipples and injection valves are used for injection joints. The injection valve is positioned on the wrap-around gauze by using the wrap-around tape. The injection nipple is placed onto the resin pack in order to enable an easy and smooth injection of the resin into the joint. Recommended for injection joints on cables  $>4 \times 25 \text{ mm}^2$



# Injection nipples and valve 12,2mm

## Spezifikationen

Material	polystyrene
Inner diameter opening	12,2mm
Outer diameter	Suitable for all common types of injectionvalves of 12,2mm
Version	Adhesive foam ring with a removable protection foilVery good adhesion, even with high and low temperatures.Suitable for all common types of resin packages.
Nipple construction	The resin package opens with the pressure of the injection pump.The nipple has 9 perforation teeth.

Injectionnipple 12,2mm

Material	Polyethylene
Inner diameter opening	14,5mm
Diameter plate	70mm
Version	Suitable for all common type of injectionnipples 12,2mm.
Valve construction	Provided with a non-return valve to prevent leakage of the resin

Injectionvalve 12,2mm

# Injection nipples and valve 12,2mm

## Produkte

Art.nr.	Artikelname	Bestelleinheit
80370	Injection nipple 12,2mm	50 pcs/carton
80560	FiloSlim Einspritzventil	10 Stück / Karton